

WSMP Solar Water Heater
INSTALLATION MANUAL

WSMP Solar Water Heater made of all-glass evacuated tube collector with heat pipe (Hereinafter ESWH).

Please take time to read this manual and familiarize yourself with the function of this product.


Content

Introduction	2
Specifications of SWH.....	2
Principle of Operation	3
Assembly Instructions	3
Reflector Assembly	3
Frame Assembly	3
Connecting frame and reflector	4
Storage tank assembly	4
Unit Mounting Instructions	4
Mounting on roof ridge	4
Mounting on roof slope	5
Glass Tube Assembly	6
Evacuated Tubes assembly	6
Precautions	8
Plumbing Instructions	8
User Instructions	8
Precautions	8
Usage and installation	9
Trouble Shooting	10

Introduction of solar water heater

The ESWH are close-coupled solar water systems made of all-glass evacuated

tube collectors with heat pipes, which are ideal for use in small buildings, houses and other applications. The ESWH can be used together with an electric booster element, thus providing hot water even on low-irradiance days. The ESWH is available in several sizes, depending on your hot water requirements.



Specification of ESWH

MODELS	JR-138	JR-158	JR-178	JR-208
Volume of storage tank	138 L	158 L	178 L	208 L
Tube	SL-I-1500	SL-I-1500	SL-I-1500	SL-I-1500
Number of tubes	18	21	24	28
Glass tube OD/inner heat pipe OD	Ø47mm/5mm			
Storage tank material	Outer shell: aluminum/zinc coated steel sheet, 0.6 mm thick Inner cylinder: SS 316L / SS304, 1.2 mm thick			
Insulation	Polyurethane foam with thickness of 45 mm			
Reflector	Flat plate diffuser, aluminum			
Frame	Aluminum profile			
Cover	Metallic			
Max. pressure	0.45 MPa	0.45 MPa	0.45 MPa	0.45 MPa
Aperture area, m ²	1.8	2.1	2.4	2.8
Net weight, kg	42	47	52	57
Collector frame angle, standard fixed	45°	45°	45°	30°
Typical daily efficiency	≥58%			
Heat loss coefficient, w/m ² °C	9.5 W/m ³ K			
Inlet/outlet connections	1/2"			
Optional electric booster	1.5 kW			2 kW

Operational Principle

The ESWH are all-glass evacuated solar domestic water systems combined with heat pipes. The selective coating in the inner cover of the evacuated tubes ensures high energy absorption and low heat radiance losses, which converts solar energy into heat energy and transfers this energy to the heat pipe by an aluminium fin. The liquid in the heat pipe changes into vapour and rises to the condenser. The heat conducts away to the water inside the tank and the vapour in the heat pipe again becomes liquid, returning to the base of the heat pipe. This continuous circulation transfers heat from the heat pipe to the cold water in the tank. This process will continue as long as the sun is heating the collectors.

Assembly Instruction

The reflector angle of ESWH heater can be chosen between 30° or 45°.

Reflector Assembly

1. Place the module-type reflectors side by side.
2. Position the base bracket with larger parallel slots at the bottom. Overlap the holes with those in the triangular end of reflector frame. Fasten with the nuts and bolts provided.
3. Position the narrow sides of the top reflector bar upwards and overlap the holes with those in the square end of the reflector frame. Fasten with the nuts and bolts provided.

Frame Assembly

Cross-connect the diagonal bars with the right and left upright supports.

In the JR-200 model, connect the two sets of crossed diagonal bars to the middle upright support. Then connect to right and left upright supports.




Fig. 2 Assembly of the unit (the collector tilt angle is 30° and 45° respectively)

Assembly Frame and Reflector

1. Face the flat surface of tank bracket outwards.
2. Insert tank bracket between top reflector bar and reflector frame, at the same time overlapping holes. Fasten with the nuts and bolts provided.
3. Fasten other end of tank bracket to right and left upright supports.
4. 45° collector angle: fasten diagonal sidebars and bottom sidebars.
- 30° collector angle: fasten 4 diagonal sidebars and bottom sidebars.
5. Attach the 4 feet.

Storage tank assembly


1. Place tank onto tank bracket cradle, inserting protruding bolts into holes. Fasten with nuts.
 2. Screw the air vent into place.
- NOTE: Leave the nuts loose as some alignment/adjustment may be necessary after fitting tubes.

Unit Mounting Instructions

Mounting on the roof ridge

The assembled unit should be placed on the roof ridge, move the unit from south to north to adjust the collector tilt angle, and ensures that the overflow pipe and inlet/outlet is vertical to the Horizon. This is recommended only on roofs with slopes of between 21° and 40°.

Note: Remove diagonal sidebars if ridge cap impedes them. Ensure other attachments can compensate for lack of diagonal sidebars.



Mounting on the roof slope

Determine roof angle.

Cut the right and left upright supports as specified in tab. 2.

Check tank is parallel with the ground, inlet/outlet pipes vertical.

Tab. 2 cutting upright supports instructions

Roof angle	15°	16°	17°	18°	19°	20°	21°	22°	23°	24°	25°	26°	27°	28°
Length to be cut off (mm)	0	0	17	43	70	96	123	149	176	202	229	255	282	308

NOTE:

1. Place the assembled unit on the North-facing slope of the roof for use in the Southern Hemisphere.
2. Ensure tank is parallel with the ground, and inlet/outlet pipes vertical. (refer to table below for details)
3. Attach system securely to the roof either by 6 mm steel wires or if ground mounted, the frame fastened to metal attachment points (not supplied) encased in cement blocks. (dimensions of each block 100×100×h (h≥50) mm). Both methods should be used in areas of high wind.
4. Connect inlet/outlet pipes to internal plumbing.
5. Insulate all external pipes and wrap in insulating foil.






Fig. 3 Unit mounted on the roof ridge

Glass Tube Assembly


Evacuated Tubes Assembly





1. Place the o rings into the recess on the copper heat pipes at the end with the large bulb.
2. Fit a black rubber wind-blocking seal to the open end of the glass tubes and take note of which end should slide into the recess in the tank. It will be easier to do this if the tube is moistened for lubrication. Slide the seal 10 cm down the tube.
3. Slide the threaded brass securing bush over the bottom of the heat pipe, insert the long thin end of the heat pipe into the aluminium fin already in the evacuated tube, leaving enough of the heat pipe exposed to allow insertion of the heat pipe into the tank and for fastening of the threaded brass securing bush.
4. Insert the heat pipe into the locating hole in the tank, and tighten up the brass locating bush of the heat pipe into the recess in the tank with enough pressure to effect a seal, but do not over tighten.
5. Push the glass tube into the locating hole in the tank; do not twist the tube to avoid damaging the inner cover of the tube.



6. Insert the tubes end into the end protector, and then clip the protector first into the shorter holes in the tube carriage, and then the left/right flexible fasteners into the longer holes in the tube carriage.



7. Slide the black rubber wind- blocking seals up the tube until the lip on the seal is flush with the tank.
8. Insert all tubes to achieve alignment of the tank and the frame before fastening the frame nuts and bolts.
9. Once fully assembled tighten all nuts and bolts.




Precautions:

1. Do not assemble in the sun unless the glass tubes are covered, the heat pipes can get hot enough to cause a burn injury, and damage to the heat pipes will occur if the hot end of the pipe contacts cold water. Only uncover the glass tubes once the tank is filled with water.
2. Do not bend, distort or crush the copper heat pipe.
3. Do not allow the copper joint of heat pipe to impact on the evacuated tubes during installation
4. Do not untwist the copper joint of the heat pipe; it was sealed in the factory, and allowing the liquid inside to escape will render the heat pipe useless.

Plumbing Instructions

For ESWH, the optional auxiliary electric controller functions as a pump control, Electric heating element control and a timer. The optional auxiliary electric controller is not displayed in Fig. 8.



Instructions:

Valve k1 remains open, valve k2, k3 remain closed when hot water is not used.

Open valve k2 when hot water is to be used, open valve k3 to adjust the water temperature if it is too hot.

Close valve k2, k3 when you want to stop using the hot water.

Precautions:

1. When the hot water is to be used, beware of scalding as the water temperature can be very high. Mix with cold water to achieve comfortable temperature before showering or bathing.
2. JB series solar water heater withstands pressure ≤ 0.5 kgf/cm
3. The evacuated tubes resist temperatures as low as -70°C when the tank is empty. Under these conditions, for the unit without auxiliary electric controller, the tank should remain filled during continuously cloudy or snowing days in winter; in addition, every two days the cold water in the tank should be changed to prevent the water in the tank from freezing which might damage the tubes.
4. Make sure the evacuated tubes are clean, hose off the dust and dirt on the tubes and the reflector before the winter.
5. Do not fill with cold water more than once in a low solar irradiance day.
6. The overflow pipe must be connected outdoors; the overflow pipe should be placed near a floor drain or drainage channel, the overflow pipe should never be blocked.
7. Do not connect a valve in the overflow pipe line.
8. Avoid using hot water from the unit washing machines.

Usage and installation FAQ

- What are the most obvious advantages of a ESWH?
 - Can be installed individually or combined with a traditional system;
 - Withstand pressure;
 - Can operate with occasional tube breakages and these can be replaced easily;
 - Works well in low-irradiance day with an electric booster
- How to avoid cold water and hot water mixing?
 - If the outflow rate is limited within 8L/min, this mixing can be avoided.
- How to clean lime off heat pipes if they have been used for a long time?
 - Carefully remove collector tubes, screw loose the heat pipe, clean the top end with chemical decontaminant.
- Why does hot water flow intermittently some times?
 - When the outflow rate is greater than the inflow, the relief valve on the top of tank will open and suck air in; the water level inside the tank will then be temporarily lower than the outlet connection, so hot water flow will stop.
 - It is recommended that more than two showers or hot taps shall not be used at the same time.
- Where to install pressure-reducing valve and safety valve?
 - The pressure-reducing valve can be installed outside near the cold water connection on the bottom of the storage tank. But the safety valve shall be installed indoors.
- What are the requirements for the piping and connections?
 - Choose good aluminium and plastic compounds with heat-resistance over 90°C.

And ask your local professionals to install your solar water heater.

Trouble Shooting

Troubles	Probable Reasons	Solutions
No water flows out	Not enough pressure or no water supply. Piping or connections have been broken off or blocked. Frozen piping	Repair pipe circulation or clean blockages away. Allow to defrost
Low hot water temperature	Low irradiance Leakage caused by loose or damaged valves/taps Collector within shadow, using too much hot water in one day.	Tighten or replace valves Take the shade away (cut branches) or mount the solar water heater where no shadow is cast on it by structures.
No continuous water	The outflow is more than the inflow.	Slow down the outflow